



### **Floating/Doweled Design Installation**

Thank you for purchasing our products! Please refer to the following instructions for installation on all types of surfaces (masonry, wood, stucco, siding, etc.)

#### **Tools:**

- Pliers
- Level
- Tape measure
- Pencil or marker
- ¼ inch masonry drill bit
- Drill (hammer drill preferred)
- Silicone or equivalent adhesive
- Rubber mallet

#### **Instructions:**

1. Install the dowels provided by turning the threaded end clockwise into the threaded holes within the number. The dowels can be fully tightened by hand but pliers can be used to ensure the dowels are fully seated.



**Figure 1:** Install the dowels

2. Hold the doweled piece against the wall in the orientation desired and mark the first dowel location. Use a level or tape measure to aid in positioning.



**Figure 2:** Mark the dowel location

3. Drill one hole at the marked location to the desired depth using a drill and a 1/4 inch diameter masonry drill bit.




**Figure 3:** Drill and masonry drill bit



**Figure 4:** Drill the first hole

4. Insert the top dowel in the drilled hole and position/level the number as desired. Mark the position of the bottom dowel. Use a level or tape measure to ensure the number is straight/level.



**Figure 5:** Mark the position of the bottom dowel

5. Drill the second hole to the desired depth at the marked location.
6. Apply silicone or construction adhesive within the holes.
7. Insert the dowels into the holes. A rubber mallet may be used to seat the dowels in the holes. Ensure the piece is protected with cardboard and a soft cloth (to prevent scratching) prior to tapping with mallet.